

Time and Date Setting


Setting the hour: When time is displayed, press and hold "B" until the hour lights flash, then tap "B" to advance.

Setting the minute: With the hour lights blinking, press and hold "B" until the minute lights flash, then tap "B" to advance.

Setting the month: With the minute lights blinking, press and hold "B" until the month lights flash, then tap "B" to advance.

Setting the day: With the month lights blinking, press and hold "B" until the day lights flash, then tap "B" to advance.

Lithium Battery CR2016, 3V.



Reading the Display

- Touch "B" to view the time.
- Touch "B" again to view the date.

- The hour/month is represented by the lights in the lefthand column. AM/PM is indicated by the "PM" light.
- The minute/day are represented by the lights in the middle and righthand columns (middle column represents 10s, right column represents 1s).