



One-touch display :

- Touch B to display time, again to view date, and again to view seconds.

Time and date setting :

- Tap B to display time, then long-press until the hour appears. Tap to adjust.
- Long-press B again to select minutes. Tap to adjust.
- Long-press B again to select the year. Tap to adjust (y00-y59).
- Long-press B again to select the month. Tap to adjust.
- Long-press B again to select the date. Tap to adjust.

When finished, wait for the display to shut off.

It will retain the settings.

Lithium Battery CR2016

Affichage One-touch :

- Touchez B pour afficher l'heure, encore une fois pour la date, et à nouveau pour les secondes.

Régler la date et l'heure :

- Touchez B pour afficher l'heure. Appui long pour sélectionner les heures. Appuis courts pour régler.
- Nouvel appui long sur B pour sélectionner les minutes. Appuis courts pour régler.
- Nouvel appui long sur B pour sélectionner l'année. Appuis courts pour régler (a00-a59).
- Nouvel appui long sur B pour sélectionner le mois. Appuis courts pour régler.
- Nouvel appui long sur B pour sélectionner le jour. Appuis courts pour régler.

Une fois fini, attendez que l'écran s'éteigne. Les réglages seront enregistrés.

Batterie au lithium CR2016