

03328 instruction tag (20141204) MX



One-touch display:

- Touch B to display time, again to view date, and again to view seconds.

Time and date setting:

- Tap B to display time, then long-press until the hour appears. Tap to



adjust.

- Long-press B again to select minutes. Tap to adjust.
- Long-press B again to select the year. Tap to adjust (y00 – y59).
- Long-press B again to select the month. Tap to adjust.
- Long-press B to select the date. Tap to adjust. When finished, wait for the display to shut off. It will retain the settings.

Lithium Battery CR2016

size:25mmX50mm